



How to Disable Driver Signature Verification


- 1) Enter **PC settings**. choose **General** on the left and click **Restart now** under Advanced startup, as shown in the following screen shot.




- 2) Click **Troubleshoot** in the next interface.




- 3) After entering Troubleshoot interface, tap **Advanced options** to enter it.



- 4) Select **Startup Settings**. Please refer to the picture below.



- 5) Click **Restart** button in Startup Settings interface.



- 6) Press **7** or **F7** to choose Disable driver signature enforcement.

